

Part Number: MV-910-R-F

Description: Front Saddle

Fitment: Augusta MV 910

Revision: 1



Tools	Parts List
Flathead screwdriver	

1. Remove your stock rear seat by turning the key on the left hand side of the bike, then lift up the rear of the saddle and pull out (Figure 1).

2. Corbin's front saddle mounts easily by using your stock Dzus fastener.

3. Remove the stock front saddle by disconnecting the Dzus fastener (Figure 2), then lift up the rear of the saddle and pull out.

4. Remove the Dzus fastener from your stock saddle by removing the plastic washer with a flathead screwdriver.

NOTE: You will not be reusing the plastic washer that was holding the Dzus fastener in place.

5. To install your Corbin front saddle, slip the front tongue of your saddle under the chassis at the rear of the gas tank, align the rear of the saddle and secure with the stock Dzus fastener. (Figure 3)

6. Reinstall the rear saddle



Questions? Give us a holler...
800-223-4332
tech@corbin.com