

Part Number: BMW-C650GT-12-E
Description: Heated Dual Saddle
Fitment: 2012-2013 BMW C650 GT
Revision: 2



Tools Required	Parts List
4mm Allen Wrench	Dual Saddle

Electric seat heater is designed to plug into the existing wiring on your BMW for simple installation.

1. Start by opening up your stock seat.
2. Unplug the heater and unclip it from the seat (*Figure 1*).
3. Remove the stock bolts by unbolting the 6 Allen screws, using a 4 mm Allen wrench (*Figure 2*).

In step 4, we recommend you cover the top and front of your gas tank and get a second pair of hands to help hold the saddle and guard from scratching the paint.

4. Bolt on the Corbin saddle, using the stock bolts.
5. Pull out enough of the stock heater pigtail (*Figure 3*) and plug it into the Corbin saddle (*Figure 4*) and then test the switch for proper function.

WARNING!

Heater elements should NEVER be installed in motorcycle seats used by riders that cannot sense heat.

Questions? Give us a holler...
800-223-4332
tech@corbin.com

