

**Part Number:** D-SCRM-G & D-SCRM-GL

**Description:** Gunfighter & Gunfighter & Lady Saddles

**Fitment:** 2015 Ducati Scrambler Classic

**Revision:** 1



| Tools Required                        | Parts List                                                                                                         |
|---------------------------------------|--------------------------------------------------------------------------------------------------------------------|
| 4mm Allen Wrench<br>8mm Socket Wrench | 1 #P11136 Bracket Plate<br>2 #SP00103 Nylon Spacers<br>2 #P01017 Button Head Allen Bolts<br>2 #P00102 Flat Washers |

1. Remove your stock seat. Refer to your owner's manual if necessary.
2. Remove the two stock bolts at the base of the gas tank, using a 8mm socket wrench (*Figure 1*).
3. Install Corbin's bracket plate where you just removed the stock bolts. Do this by first putting the nylon spacers into place, then bracket, washer and button head Allen bolts (*Figure 2*). Secure by using a 4mm Allen wrench.



FIG 1

3. To install your Corbin saddle, slip the front tongue of your saddle under the bracket you just installed, align the rear of the saddle with the rear stock locking mechanism and push down on the saddle until you hear the lock click (*Figure 3*).



FIG 2



FIG 3

Questions? Give us a holler...  
**800-223-4332**  
tech@corbin.com