

Part Number: KD-8-DT

Description: Dual Touring Saddle

Fitment: 1999-2006 Kawasaki Vulcan Drifter 800

Revision: 1



Tools Required

8mm socket or combination wrench
10mm socket or combination wrench
12mm socket or combination wrench

1. First to remove your stock seat. Remove 2 side seat bolts (1 on each side) with a 8mm wrench (Figure 1).
2. Now remove the nut from the bottom of the seat (Figure 2) using a 10mm wrench.
3. Next lift the rear of the seat and pull back to remove seat.
4. Now that your seat is off lets take your seat sub frame off. Remove 4 seat bolts (2 on each side) using a 12 mm wrench (Figure 3), holding on to your seat sub frame so as not to drop it on your rear fender.
5. Next is to install your Corbin's Custom Saddle with the seat sub frame built in. Reinstall the 4 seat side bolts (2 on each side) (Figure 4), making sure that the tongue is under the bracket of the seat up front, with a 12mm wrench. Now torque these bolts (using loctite) to 20 ft. lbs.



Questions? Give us a holler...
800-223-4332
tech@corbin.com