

Part Number: KV-2-ST6-FAIR

Description: Touring Fairing

Fitment: 2006 Kawasaki Vulcan 2000

Revision: 1



Tools Required	Parts List
T30 Torx Key 5mm Allen Key	4 m8 x 1.25 x 40 Chrome button head bolts 4 8mm x 1.25 x 25mm Chrome button head bolts 12 8mm flat washers 1 #A00836 Chrome fairing bracket (left) 1 #A00837 Chrome fairing bracket (right)

NOTE: We recommend the use of Loctite® or other threadlock material when assembling parts on your motorcycle.

1. Assure that you have all of the parts necessary for installation. The two Corbin fairing mount brackets are NOT the same but are a near mirror image of each other.

2. Fairing installation is simple and requires only that our brackets be installed onto your front end.

3. To install, remove the top and bottom chrome button head bolts on the headlight shroud using a T30 torx wrench (*Figure 1*). Do this one side at a time to keep the headlight shroud cover in place while you do the installation of the brackets.

4. Now position the Corbin bracket with the supplied washers between the Corbin bracket and your bike (*Figure 2*) and secure with the provided 8mm x 1.25 x 25mm chrome button head bolts and 8mm flat washers (*Figure 3*). Use Loctite® on these bolts and tighten to 12 ft. lbs.

5. Repeat this procedure on the other side.

6. You are now ready to place the fairing and attach it to the brackets. You can most likely position the fairing and have it sit by itself while you bolt it on, but we think it's a good idea to have a friend help. Just to guard from scratching the new paint.

7. Secure the fairing to the bracket using the supplied m8 x 1.25 x 40 chrome button head bolt and flat washer at each of the four locations (*Figure 4*). Use Loctite® on these bolts and tighten to 6 ft. lbs.

NOTE: Fairing was designed with handlebars and mirrors in the stock location. Check clearance so vibrations won't bring fairing into contact with painted objects.

NOTE: Corbin's Touring Fairing Accepts standard Harley-Davidson FLH windshields / windscreens in a variety of styles and sizes if you'd like to customize your fairing.



Questions? Give us a holler...
800-223-4332
tech@corbin.com