

Part Number: KTM-690SMCEN-8

Description: Dual Sport Saddle

Fitment: 2008 KTM 690 SMC

Revision: 1



Tools Required	Parts List
10mm socket wrench	

Saddle mounts to your KTM just like stock with brackets preinstalled on the Corbin seats.

1. Remove stock seat.
2. Remove the stock seat mounting tab with a 10mm socket wrench (*Figure 1*).
3. To install your new Corbin saddle, simply slide the saddle onto the bike nose first (*Figure 2*), then lower the seat into position and align the latch mechanism to the stock locking system and push down until you hear one click. (*Figure 3*)
4. To release use the stock pull tab.



Questions? Give us a holler...
800-223-4332
tech@corbin.com