

Part Number: KTM-950SM-7

Description: Dual Sport Saddle

Fitment: 2007 KTM 950 SM

Revision: 1




Tools Required	Parts List
4mm Allen Key Phillips Screwdriver	1 6m x 1.25 x 20m Chrome Allen bolt 1 6m Chrome flat washer 1 #P020241 Spacer

Saddle mounts to your KTM just like stock with brackets preinstalled on the Corbin seats.

1. Remove stock seat.
2. Remove the stock bolt on the gas tank with a phillips screwdriver (*Figure 1*) and replace it with the supplied Allen bolt, flat washer and spacer, using a 4mm Allen key (*Figure 2*). Tighten to 8 ft. lbs. and use Loctite®.
3. Simply slide the saddle onto the bike nose first engaging the tongue. Lower the seat into position and align the latch mechanism to the stock locking system and push down until you hear one click. (*Figure 3*)

NOTE: All brackets are adjustable to get the best fit.

4. To release use the stock key.



Questions? Give us a holler...
800-223-4332
tech@corbin.com