

Part Number: P-OT-6

Description: Dual Sport Saddle

Fitment: 2006 Polaris Outlaw Quad

Revision: 1



Tools Required	Parts List
3mm Open Wrench	1 #A00808 Mounting Bracket 2 10 x 24 x 3/4" Allen Bolts 2 Keys

Installation: Corbin's quad saddle uses a new key lock system for simple installation. All brackets and hardware are included. Locking mechanism and mounting tabs come preinstalled on the saddle. You only have to mount the latch pin bracket and you're ready to go.

1. Rear of saddle is held down with a latch pin bracket you will install.
2. To install, simply mount the included latch bracket in place as shown in *Figure 1*. Remove the stock bolts and washers from this position, locate bracket and secure with the included Allen bolts. Tighten to 8 ft lbs.
3. Once the latch pin is installed, slide the saddle into position nose first, making sure the top and bottom seat tongue brackets hook correctly (just like stock) and push down on the rear to latch in place. To remove, just use the key latch included in the right side of the saddle (*Figure 2*).

NOTE: If your saddle does not latch, it's due to the rubber grommets needing time to break in. To latch your saddle, adjust the latch pin upwards with a washer or two.



FIG 1



FIG 2

Questions? Give us a holler...
800-223-4332
tech@corbin.com