

Part Number: V-O-G & V-O-GAM
Description: Gunfighter & Gambler Saddle
Fitment: 2017 Victory Octane
Revision: 1



Tools Required	Parts List
6mm Allen Wrench	1 #P11155 Spacer

1. Begin by removing your stock seat(s). Refer to your owners manual if necessary.

2. Seat installs with stock front mounting screw. Just add our spacer and the tab will latch into place. (Figure 1).

3. To install your saddle, slide your seat nose first, towards the rear of the gas tank, engaging the pin bolt (Figure 2). Then slowly lower the seat down and secure the rear tab to the fender, using the stock bolt or as shown here, a Stainless Steel Thumbscrew (sold separately). Figure 3.

NOTE: Rear tab is adjustable to assure a perfect fit.

Enjoy your new saddle!



FIG 1



FIG 2



FIG 3

Questions? Give us a holler...
800-223-4332
tech@corbin.com