

Part Number: T-TGR-7

Description: Canyon Dual Sport Saddle

Fitment: 2007 Triumph Tiger

Revision: 1



Tools Required	Parts List
3/36" Allen wrench	Canyon Dual Sport

1. Remove your stock seat. Refer to your owner's manual if necessary.
2. Saddle mounts just like stock with brackets preinstalled on the saddle.
3. To install your Canyon Dual Sport saddle, slip the two front tongues of your saddle under the rear of the gas tank, align the corbin bracket to the stock bracket and push down on the saddle until you hear the lock click. (Figure 1)

NOTE: If you will be using the rider's backrest, install it before latching seat to bike. There is a safety screw that must be installed and you cannot reach it with the seat mounted on.

4. To install the optional backrest, you will need to slide the backrest shaft through the opening on the top seat cover, then secure it into place, through the bottom with the supplied Allen screw, using a 3/16" Allen wrench (Figure 2).



FIG 1



FIG 2

Questions? Give us a holler...
800-223-4332
tech@corbin.com