


Part Number: BMW-RT14-E-SMUG
Description: Front Saddle and Smuggler
Fitment: 2014 BMW R1200 RT
Revision: 2

Corbin

Tools Required	Parts List
Wire Crimper Wire Cutters Phillips Screwdriver	1 #P11306 Latch Pin Mounting bracket 2 #SP00974 6mm x 16 Button Head Allen Bolts 2 #SP00176 Large Fender Washers 5 Male connectors 5 Female connectors

1. Remove the stock seat(s) from your bike.
2. To install the Corbin bracket you need to remove the two hex head bolts on the inner fender. (*Figure 1*)
3. Install the Corbin mounting bracket where you just removed the hex head bolts by inserting the two button head Allen bolts through the bracket, then add the large fender washers (*Figure 2 & 3*).



4. **Electric Heat Installation:** Start by cutting the stock front and rear seat wiring harness in half, then trim 3" of tubing to expose the wires. (*Figure 4*)



5. For the front wiring harness, remove 1/2" of the plastic covering (*Figure 5*) from the brown wire, making sure to be careful to not cut through the wires, then twist the copper wires together, bend them over in half, then crimp the female connector onto it (*Figure 6*). Do the same to the purple wire, but crimp the male connector onto it. This should reflect the opposite as the Corbin seat wire connectors (*Figure 7*).



6. For the rear wiring harness, remove 1/2" of the plastic covering from each wire, making sure to be careful to not cut through the wires. Twist the copper wires together on the green/white wire, bend them over in half, then crimp the male connector onto it. Do the same to the brown, yellow/white and blue/white wires, but crimp the female connectors onto them (*Figure 8*).

7. Plug the BMW connectors to your stock harness.

8. Next you are going to connect the front BMW connectors to the front pigtail on the Corbin seat. Connect the purple wire on the Corbin seat to the BMW purple wire. Do the same with the brown wire.

9. Now connect the rear BMW connectors to the rear pigtail on the Corbin seat. Connect the brown wire on the Corbin seat to the BMW brown wire, then the purple wire connect to the green/white wire, the yellow wire connect to the yellow/white wire and the blue wire connect to the blue/white wire. Now slide the front tab of your saddle under the front seat mount at the rear of the gas tank, align the rear Corbin bracket to the locking mechanism and push down on the saddle until you hear the lock click.

10. To remove the saddle and smuggler, push the lever inside the smuggler trunk and lift off. (Figure 9)

NOTE: The rear heater operates by the switch on along the side of the saddle. The front heater operates on the dash controls.



FIG 5




FIG 6




FIG 7




FIG 8



FIG 9

Questions? Give us a holler...
800-223-4332
tech@corbin.com