

Part Number: S-M109R-FAIR-2

Description: Fleetliner Fairing

Fitment: 2006-2016 Suzuki Boulevard M109 R

Revision: 2



Tool Required	Parts List
10mm Allen socket ball head 6mm Allen key 4mm Allen key 10mm Open wrench 8mm Open wrench #2 Phillips Screwdriver	1 #A00857 Top Mounting Bracket 1 #A01037 Bottom Mounting Bracket 2 8mm x 40 Chrome Button Head Allen Bolts 1 8mm x 20 Chrome Button Head Allen Bolts 3 5/16" Chrome Flat Washers 2 1/4" Chrome Flat Washers 2 6mm x 1.25 Nylock Nuts 4 6mm Flat Washers 4 6mm x 1 x 12 Chrome Button Head Allen Bolts 1 ABS Ceville Head Light Cover Extension 4 #P00738 Black Nylon Washers

NOTE: We highly recommend using a medium strength thread lock product, such as Loctite®, on all of the bolts when installing your Corbin Fairing.

1. Remove the plastic clips on top of the housing by using a pointed object small enough to fit into the pin hole. The point of a pencil or pen should do the trick. Push in the button in the center of the clip to release (*Figure 1*). Discard clips as you will not need them anymore.



2. Remove the headlight housing by removing the bolts on the side of the headlight, using a 4mm hex key (*Figure 2*).



3. Remove the phillips screws on the painted and chrome plastic parts on the inside of the headlight housing.

NOTE: You won't be reusing these parts.

4. Next, secure the headlight with the supplied Nylon black washers and the stock bolts. To do this, slip two nylon washers onto the stock bolt and screw it in (*Figure 3*). Do the same on the other side. Don't forget to use Loctite®, then tighten to 8 ft. lbs.



In the following steps, we recommend you cover the top and front of your gas tank and get a second pair of hands to help hold the handlebars and guard from scratching the paint.

5. Remove the handlebar risers, using a 10mm socket wrench Allen key under the top clamp (*Figure 4*).

NOTE: You can turn the wheel to one side to get better access to the bolts.

6. Install the Corbin bracket #A00857 onto the handlebar riser, making sure the stock rubber grommet is on the bottom and the stock washer is on the top (*Figure 5*). Secure them in place by using the stock bolts. Tighten to 12 ft. lbs. and use Loctite®.

7. Install the Corbin ABS backlight extension, by using the supplied 10mm button head Allen bolts, washers and Nylock nuts (*Figure 6*).

8. Next, install the bottom mounting bracket #A01037 onto the bottom of the headlight. Start by removing the two 8mm Allen bolts, place the bracket in place with the bend corner facing upwards towards the headlight and secure it in place using the stock bolts (*Figure 7*). Use Loctite® and tighten to 10 ft. lbs.

9. You are now ready to mount the Fairing. It would be a good idea to get a second pair of hands to help you hold the fairing up while you bolt it in place (*Figure 8*). Two bolt locations are on the top left and right side and the third one is located at the bottom under the headlight (*Figure 9*). Get all the bolts started, then tighten them up to 8 ft. lbs and don't forget to use Loctite®.

10. Secure the plastic backing to the fairing, using two 6mm x 1 x 12 chrome button head allen bolts and flat washers. (*Figure 9*)



FIG 4



FIG 5



FIG 6



FIG 7



FIG 8



FIG 9

Questions? Give us a holler...
800-223-4332
tech@corbin.com