
Part Number: H-24TA-E

Description: Canyon Dual Sport Saddle **Fitment:** 2023 - 2024 Honda Transalp 750

Revision: 1



SADDLE INSTALLATION:


- 1. Remove your stock seat. Refer to your owner's manual if necessary.
- 2. Saddle mounts just like stock and integrates with your Honda key lock system.
- 3. To install your Dual Saddle, slip the front bracket of your saddle under the two front seat mounting hooks, align the rear locking bracket on the saddle to the stock locking position (*Figure 1*) and push down on the saddle until you hear the lock click.

HEATER INSTALLATION:

- 1. If you ordered the heated model, we also included a wiring pigtail that hooks into your stock fusebox, so start by removing the fusebox cover (*Figure 2*).
- 2. Remove the 10 amp fuse from the METER / ILLUMI / HORN position (Figure 2 & 3) and insert the fuse into the adapter at the end of the wiring pigtail (Figure 4).
- 3. Insert the adapter in the space previously occupied by the 10amp METER / ILLUMI / HORN fuse (Figure 5).
- 4. With the pigtail in place, the stock cover will not go back onto your fusebox. Insert the adapter through the included rain cover, then cover the entire fusebox with the rain cover (*Figure 6*).














- 5. Connect the ground wire to the negative battery terminal, using a 10mm socket wrench (Figure 7).
- 6. Plug the two pigtails together (Figure 8).
- 7. Bundle loose wiring and secure with the included zip ties (*Figure 9*). Do not tighten excessively or you may damage the wiring... just secure it in place for cleanliness.
- 8. Be sure you have left enough wire on the wiring harness to reach the seat.
- 9. Plug the wiring harness (*Figure 10*) into the seat and test. To do this, turn on your ignition switch and flip the switch on the saddle. If the switch illuminates, the saddle heater is working.
- Proceed with saddle mounting as outlined above.


Enjoy your new saddle!

NOTE: The heater is controlled by the switch along the side of the saddle. The temperature is regulated by an internal thermostat when the heater switch is turned on.











Questions? Give us a holler... 800-223-4332 tech@corbin.com