

Part Number: HDRKCV08-6FAIR

Description: Fleetliner Fairing

Fitment: 2008 Harley-Davidson Road King

Revision: 1



| Tools Required | Parts List | |
|---|--|---|
| 5 mm Allen wrench 3/16" Allen wrench 1/2" Socket wrench or combination wrench 1/2" Open wrench 5/8" Open wrench | 1 #A00780 Chrome fairing bracket (left) 1 #A00779 Chrome fairing bracket (right) 2 #A00994 Turn signal brackets 4 8m x 1.25 x 40 Chrome button head bolts | 4 5/16 x 18 x 1 1/4" Chrome button head bolts 8 5/16" washers 4 nylon spacers |

NOTE: We recommend the use of Loctite® or other threadlock material when assembling parts on your motorcycle.

1. Assure that you have all of the parts necessary for installation. The two Corbin fairing mount brackets are NOT the same but are a near mirror image of each other.



2. Refer to *Figure 1*. Fairing installation is simple and requires only that our brackets be installed onto your nacelle with two included bolts per side. This image will also help you determine which bracket is for the left side and which is for the right side.

3. To install, remove the stock bolts on the light bar bracket, using a 1/2" wrench. Do this one side at a time just to keep things easy. (*Figure 2*)



NOTE: To remove the top stud, double nut it or use a pair of pliers.

4. Remove the rubber windshield mounts if applicable and discard.

5. Now secure the Corbin bracket as shown in *Figure 3*. Use one of the included 5/16 x 18 x 1 1/4" button head screws (short one) and a flat washer at the top and at the bottom. Use Loctite® on these bolts and tighten to 12 ft. lbs.



NOTE: When installing the top bolt, you may need to squeeze the light bracket to make it fit properly.

NOTE: If there isn't a light bracket or if you have a Road King Custom, you will need to use the provided nylon spaces between the bracket and the nacelle.

6. Repeat this procedure on the other side.



7. Next, remove the turn signals from the handlebars.

8. Install the supplied Corbin bracket #A00994 onto the turn signal (*Figure 4*) then secure it back onto the handlebars with the stock bolts and acorn nuts (*Figure 5*). Use Loctite®.

9. You are now ready to place the fairing and attach it to the brackets. You can most likely position the fairing by yourself, but we think it's a good idea to have a friend help. Just to guard from scratching the new paint.

10. Secure the fairing to the brackets with the supplied 8m x 1.25 x 40 chrome button head bolts and flat washers at each of the four locations (*Figure 5*). Use a 5mm Allen wrench and tighten to 8 ft. lbs. (*Figure 6*) Don't forget to use Loctite®.

11. Assure that everything looks sano with no pinched wires or crimped hoses and you're ready to go show 'er off. Enjoy the ride!



Questions? Give us a holler...
800-223-4332
tech@corbin.com