

**Part Number:** T-TB-9-FAIR

**Fitment:** 2009-2010 Triumph Thunderbird

**Revision:** 2



Tools Required	Parts List
8mm socket or open wrench 10mm open wrench 7/16" open wrench 3/16" Allen wrench 8mm Allen wrench 4mm Allen wrench level Loctite® or similar thread lock. <b>REMOVABLE STRENGTH</b>	1 Corbin top bracket (#A01104) 1 Corbin lower bracket (#A01105) 2 Handlebar spacers (#P11047) 8 6mm flat washers 2 1/4 x 20 nylock nuts 2 1/4 x 20 x 2.5 Allen bolts 4 6 x 16 chrome Allen bolts 4 6mm nylock nuts 4 8mm x 40 x 1.25 chrome Allen bolts 4 3/8" flat washers

**NOTE:** Cover the tank and fender to help prevent from scratching.

**NOTE:** It may also be helpful to have a second set of hands to help hold the fairing in position during the last step.

**NOTE:** We highly recommend using a removable strength thread lock product, such as Loctite® blue, on the bolts when installing your fairing.

1. Before removing the headlight, use a level to determine the angle it is in, so when you reinstall the headlight, you can put it in the same position (*Figure 1*).



2. Remove the two bolts on the headlight, using a 10mm and 8mm open wrench (*Figure 2*). Rest the headlight on the fender and discard the bolts (*Figure 3*).



3. Using a 8mm Allen wrench, remove the bolts on the handlebars (*Figure 4*).



4. Replace the stock spacer with the Corbin spacer. (*Figure 5*).

5. Rest the handlebars on the tank and remove the rubber bushings on the triple clamp and set them aside.

6. Place the Corbin bracket on top of the triple clamp and under the cables (*Figure 6*). Put the rubber bushings back in place (*Figure 7*). Place the handlebars on top of the rubber bushings and secure with the stock bolts and the longer Corbin spacer. Use Loctite® and tighten to 12 ft. lbs.

7. Next, you are going to slide the lower bracket into position where you took out the bolts on the headlight, making sure the headlight cables are in between the bracket (*Figure 8*).

**NOTE:** You may need to wet the inside of the bracket to make it easier to slide over the rubber grommets.

8. To secure the bracket in place, slide the supplied 1/4" x 20 x 2.5" Allen bolts and 6mm flat washers through the bracket and secure with a 6mm flat washer and 1/4" x 20 nylock nut, using a 3/16" Allen wrench and 7/16" open wrench (*Figure 9*). Tighten to 8 ft. lbs.

9. Reinstall the headlight and secure it with the supplied 6mm x 16 chrome Allen bolts, 6mm flat washer and 6mm nylock nuts (*Figure 10*), using a 4mm Allen wrench and 10mm open wrench. Do not tighten yet.

10. Re-adjust the headlight, then tighten to 8 ft. lbs.





11. Install the fairing by securing it with the supplied 8mm chrome Allen bolts and 3/8" flat washers in each of the four positions (Figure 11). Don't forget to use Loctite®.



FIG 8



FIG 9




FIG 10



FIG 11

Questions? Give us a holler...  
**800-223-4332**  
tech@corbin.com