

Part Number: T-R3-20-FAIR & T-R3-20-AU

Description: Touring Fairing & Audio Kit

Fitment: 2020 Triumph Rocket III

Revision: 1



Tools Required	Parts List
6mm Allen Wrench 5mm Allen Wrench 6mm Ratchet Allen Wrench T-30 Torx Wrench Red Loctite® or similar thread lock.	1 #A01310 Top Mounting Bracket 1 #A01311 Right Mounting Bracket 1 #A01312 Left Mounting Bracket 4 8mm x 70mm x 1.25 Cap Head Allen Bolts 8 8mm Lock Washers 4 8mm Flat Washers 4 6mm Flat Washers 4 8mm x 45mm x 1.25 Allen Bolts

NOTE: Cover the tank and fender to help prevent from scratching.

NOTE: It would be helpful to have a second set of hands during this installation to help hold some of the parts in position while installing the fairing.

NOTE: We highly recommend using a removable strength thread lock product, such as Loctite® red, on the bolts when installing your fairing mounting brackets.

1. Start by placing a jack under the bike to keep the bike straight and to keep the weight off of the forks. You don't need to lift the bike, it's just for support (*Figure 1*).

2. To gain access to the turn signal bolts, you need to remove the two bolts holding the headlights, using a 6mm ratchet Allen wrench. Catch the bracket that's holding the headlights in place (*Figure 2*), then let headlights hang in place (*Figure 3*).

3. Loosen the bolt on the turn signal, using a 5mm Allen wrench (*Figure 4*), then slide the turn signal down, approximately 2 1/4" from the top of the triple clamp (*Figure 5*) and then snug the bolt in place.

NOTE: Gently pull turn signal wire as you slide it downwards.



FIG 1



FIG 2



FIG 3



FIG 4



FIG 5



FIG 6

4. Repeat on the other side and then tighten the bolts on both the right and left side.

5. Reinstall the headlight.

NOTE: The longer leg on the bracket, faces towards the front (*Figure 6*).

6. Remove the four bolts on the small windshield, using a T-30 torx wrench (*Figure 7*).



7. Remove the two bolts on the left plastic stand under the windshield you just removed (*Figure 8*), using a T-30 torx wrench. Set stand aside and then use the supplied 6mm flat washers and OEM bolts you just removed and put back into place where you removed the plastic stand (*Figure 9*). Snug bolts into place.



8. Repeat on the right side and then tighten all four bolts, but do not over tighten.

9. On the next step, you may want a second pair of hands to hold the handlebars, so they don't fall down.

10. Remove the two top handle bar bolts (*Figure 10*).

NOTE: You may want to use a piece of tap to mark the position of the handlebars if they move.

11. Align the holes on the top mounting bracket to the holes on the handlebars and secure with the supplied 8mm x 70 mm x 1.25 cap head Allen bolts, 8mm lock washers and 8mm flat washers, using a 6mm Allen wrench (*Figure 11*). Use a drop of red Loctite® and then tighten in place. Tighten to 14 ft. lbs.



12. Install the right mounting bracket by first removing the bottom bolt on the right top triple clamp (*Figure 12*). Discard bolt. Then install the the right mounting bracket, making sure the angle is the same as the top mounting bracket, then secure with the supplied 8mm x 70 mm x 1.25 cap head Allen bolts, 8mm lock washers and 8mm flat washers, using a 6mm Allen wrench (*Figure 13*).



Adjust the bracket by measuring 8" from the top mounting bracket to the lower mounting bracket, center to center of holes (Figure 14). Use a drop of red Loctite® and then tighten in place.

13. Repeat on the left side.

14. On the next step, you may want a second pair of hands to hold the fairing in place, while you secure the fairing to the mounting brackets.


15. If you have the stereo kit option, plug the wire into the accessory plug on your bike (Figures 15 & 16).

16. Install the fairing by aligning the mounting points on the fairing (Figure 17) to the mounting points on the brackets and then secure using the supplied 8mm x 45mm x 1.25 Allen bolts, 8mm lock washers and 8 mm flat washers in each of the four positions (Figure 18). **DO NOT** use Loctite®. Tighten to 3.5 ft. lbs.

NOTE: Make sure the stereo wire isn't pinched before securing and tightening the bolts.

17. Check to see if the stereo system is working by turning it on and connecting to your bluetooth (Figure 19).

Enjoy!



Questions? Give us a holler...
800-223-4332
tech@corbin.com